Distributed by:

JAMECO® ELECTRONICS

www.Jameco.com ✦ 1-800-831-4242

The content and copyrights of the attached material are the property of its owner.

BS2-IC MODULE Rev. F





Connect DSR and RTS for automatic port detection.

PC - to - BS2-IC connection